

Thank you for choosing a NIVELCO instrument.

1. APPLICATION

The UNICONT PJK-1□□-4 is a universal interface module that can be controlled via HART or Modbus protocol through an RS485 interface, and (depending on type) provides relay(s) and/or 4...20 mA current output(s).

The device is intelligent, the internal functions and services can be set with the help of a communication protocol: the transmitter outputs can be scaled. The error detection function can be switched on and off. The state, in which a given output unit should be when an error occurs, can also be set. The device can be used with our MultiCONT PRO-1□□-□ units as an output extension module, and also as a peripheral device for PLC or PC controlled process control systems.


2. TECHNICAL DATA

2.1 GENERAL DATA

PJK-1□□-4	
Supply voltage	24 V DC ± 10%
Power consumption	(10 mA + N ^(*) Relay X 11 mA + N ^(*) Current generator X 25 mA) ± 10%
Ambient temperature	-20...+50 °C (-4...+122 °F)
Electrical connection	max. 2.5 mm ² (AWG14) twisted, max. 4 mm ² (AWG12) solid wire
Mechanical connection	DIN EN 60715 rail
Ingress protection	IP20
Weight	≈ 0.11 kg (≈ 0.25 lbs)


(*)N: number of outputs of a given type of output units

2.2 TYPE SPECIFIC DATA



OUTPUT UNITS	TYPE (A)	PJK-102-4		PJK-111-4		PJK-110-4		PJK-120-4	
		B	C	B	C	B	C	B	C
Relay	Output	1x SPDT		1x SPDT		1x SPDT		1x SPDT	
	Rating	250 V AC, 8 A, AC1		250 V AC, 8 A, AC1		250 V AC, 8 A, AC1		250 V AC, 8 A, AC1	
	Insulation voltage	2500 V 50 Hz		2500 V 50 Hz		2500 V 50 Hz		2500 V 50 Hz	
	Electrical / Mechanical life span	10 ⁵ / 2 x 10 ⁶ switches		10 ⁵ / 2 x 10 ⁶ switches		10 ⁵ / 2 x 10 ⁶ switches		10 ⁵ / 2 x 10 ⁶ switches	
	Pulse width in pulse mode	0.1...25.5 s		0.1...25.5 s		0.1...25.5 s		0.1...25.5 s	
Current generator	Linear range	-		-		3.601 mA...21.999 mA		3.601 mA...21.999 mA	
	Error indication	-		-		≤ 3.6 mA or ≥ 22 mA		≤ 3.6 mA or ≥ 22 mA	
	Resolution	-		-		14 bit		14 bit	
	Accuracy	-		-		40 μA		40 μA	
	Temperature dependence	-		-		max. 15 μA / 10 °C		max. 15 μA / 10 °C	
Maximal load resistance	-		-		≤ 800 Ω		≤ 800 Ω		

2.4 DIMENSIONS



2.5 ORDER CODE

P J K - 1 □ □ - 4

CURRENT OUTPUT	CODE	RELAY	CODE
-	0	-	0
1x 4...20 mA	1	1x SPDT	1
2x 4...20 mA	2	2x SPDT	2

3. MOUNTING


The PJK-1□□-□ device can be mounted on a DIN EN 60715 rail.

4. ELECTRICAL CONNECTION

4.1 ELECTRICAL CONNECTIONS OF POWER SUPPLY AND OUTPUTS

POWER SUPPLY	RELAYS	CURRENT GENERATORS
- , + Terminals of the 24 V power supply. <i>Make sure that the wiring is done with correct polarity!</i>	De-energized relay: - common contact C - normally open contact NC - normally closed contact	I- - negative current output I+ - positive current output

4.2 RS485 COMMUNICATION TERMINALS




TB - terminator contact, interconnect with point "B"
B - negative terminal of RS485 data connection
A - positive terminal of RS485 data connection
SHLD - shielding

The Universal Interface Modules should be connected one after another to one cable pair. Star topology is not allowed. Max. cable length is 1000 m, but in this case a shielded twisted cable pair (STP - Shielded Twisted Pair) should be used. Max. cable capacity should be less than 100 pF/m. All of the Universal Interface Modules in one system should have different addresses (0...31), see: 5.1.2.

Wiring example when using a MultiCONT:

Connection with shielded twisted pair cable, shielding is grounded at one point on the MultiCONT side.

The terminal resistor is connected to the two farthest points of the cable. (TB and B contacts are connected in PJK 100; and on the MultiCONT the K2 terminal resistor, located next to the terminals, is switched on.)



5. INSTALLATION, SETTING UP AND PROGRAMMING


5.1. PREPARATION

5.1.1 CHOOSING A COMMUNICATION PROTOCOL

Open the housing via the four snap-on clips to access the DIP switch for protocol selection. DEFAULT SETTING: HART

5.1.2 SETTING THE DEVICE ADDRESS

A communication line can contain max. 32 Universal Interface Modules. These modules should have different addresses. Set the address with the „ADDRESS“ DIP switches (0...31), on the front panel of the device. Settings will take effect when the unit is switched on again!



Example for setting the address:
4 + 8 = 12

UNICONT

PJK-100
UNIVERSAL INTERFACE MODULE

User's manual



Manufacturer:

NIVELCO Process Control Co.
H-1043 Budapest, Dugonics u. 11.

Phone: (36-1) 889-0100

E-mail: sales@nivelco.com www.nivelco.com



2.3 ACCESSORIES

- User's Manual
- Certificate of Warranty
- EU Declaration of Conformity
- Description of the Communication Protocol

5.2. WIRING

See: "2. Technical Data" and "4. Electrical connection"

5.3. INSTALLATION

5.3.1 POWER ON AND SELF TEST

After correctly wiring and switching the device on, it runs a few self tests whose results are shown with LED indications.

SEQUENCE OF SELF TESTS	'COM.' LEDs		'STATUS' LEDs	
	1 st	2 nd	1 st	2 nd
1. Test of red LEDs	Red		Red	
2. Test of green LEDs	Green		Green	
3. DIP switch test	Blinking green	Dark	Dark	Dark
result	Green: OK. Red: Error	Dark	Dark	Dark
4. RESET button test	Green: OK. Red: Error	Blinking green	Dark	Dark
result		Green: OK. Red: Error	Dark	Dark
5. Detecting Relay on 1 st unit	Green: OK. Red: Error	Blinking green Green: Exists Red: Error Dark: Doesn't exist	Blinking green	Dark
result			Dark	
6. Detecting Relay on 2 nd unit	Green: OK. Red: Error	Blinking green Green: Exists Red: Error Dark: Doesn't exist	Blinking green	Dark
result			Dark	
7. Detecting Current output on 1 st unit, (if relay doesn't exist)	Green: OK. Red: Error	Blinking green Green: Exists Red: Error Dark: Doesn't exist	Blinking green	Dark
result			Dark	
8. Detecting Current output on 2 nd unit, (if relay doesn't exist)	Green: OK. Red: Error	Blinking green Green: Exists Red: Error Dark: Doesn't exist	Blinking green	Dark
result			Dark	
9. Peripheral self test results for 1 sec				
10. EEPROM block test result (block1, block2)	Green: OK. Red: Error	Green: OK. Red: Error		
If content of one block is erroneous, it is corrected from the other one, if both are erroneous, they are corrected by loading default values	Green: OK	Green: OK		
11. RAM, ROM, EEPROM tests and their results	Device is ready Pale green	Device is ready Pale green	Dark	Dark
Device is unable to operate	Red blinking together			

5.3.2 OPERATION

- After the self test sequence, if the device is ready for operation, states and operation of the module and its units are shown as follows:

- 'COM' LED – indicates the communication with the unit that belongs to it, (all LEDs flash in case of communication with the module), it also indicates the operation state of the device.
- 'STATUS' LED – indicates the state of the unit that belongs to it.

OPERATION STATES			
LED	DISPLAY	COMMENT	
COM.	PALE GREEN	Device is ready	
	GREEN FLASH	Successful communication	
	RED FLASH	Communication failure	
	RED	Communication cycle time-out	
STATUS	DISPLAY:	RELAY UNIT	CURRENT GENERATOR UNIT
	GREEN	Energized	Current in linear range
	DARK	De-energized	-
	RED	-	Error (signal) current
	BLINKING RED	Relay error	Current generator error

5.3.3. PROGRAMMING, SETTING THE CURRENT GENERATOR AND RELAY OPERATION

Depending on the application, re-programming of the device may be needed. Programming can be done with either a PC that controls the communication network via HART or Modbus protocol, or a MultiCONT (see MultiCONT's User Manual). Parameters determining the operation:

PARAMETERS AVAILABLE FOR ALL UNITS:			FACTORY SETTING
Communication watchdog			Off
RELAY UNIT PARAMETERS:	FACTORY SETTING	CURRENT GENERATOR UNIT PARAMETERS:	FACTORY SETTING
- 0...25.5 s pulse time (non-restartable)	0.1 s	- Configurable error-current ≤ 3.6 mA or ≥ 22 mA:	Off Off Calibrated
- Configurable energized or de-energized error state:	Off Off	- for device hardware error	
- for device hardware error		- for comm. cycle time-out	
- for comm. cycle time-out			

5.3.3.1 MODBUS COMMUNICATION PROTOCOL

Physical format: RS485, Slave, RTU, 9600 Baud, 1-8-Odd-1. Registers of the device can be accessed (read or write) with command 3 (Read Holding Registers) and command 16 (Preset Multiply Registers). Device address is adjustable in 1...31 range only. Detailed description of registers can be found in a separate document.

5.3.3.2 HART® COMMUNICATION PROTOCOL

Physical format: RS485, Slave, RTU, 9600 Baud, 1-8-Odd-1. Device address is adjustable in 1...31 range. Detailed description of HART® (standard 5) commands can be found in a separate document.

Logical set-up of the device:

Modul Factory: 151 Type: 50 ID: xxxxxx Polling: 0..31	Unit 1. Factory: 151 Type: 51 ID: xxxxxx+1	Unit 2. Factory: 151 Type: 51 ID: xxxxxx+2
--	--	--

Interpreted commands

COMMAND CODE	ADDRESSING		Module-level HART commands
	SHORT	LONG	
0	•	•	Read Unique ID
6	•	•	Write Polling Address
7	•	•	Read Polling Address
12	•	•	Read Message
13	•	•	Read Tag, Descriptor, Date
16	•	•	Read Final Assembly Number
17	•	•	Write Message
18	•	•	Write Tag, Descriptor, Date
38	•	•	Reset 'Config Change Flag'
140	•	•	Write Device ID
200	•	•	Read Device Table
206	•	•	Read Firmware Version
Unit-level HART commands			
13	-	•	Read Tag, Descriptor, Date
18	-	•	Write Tag, Descriptor, Date
201	-	•	Read Slot Output/Input
202	-	•	Write Slot Output
203	-	•	Read Slot Configuration
204	-	•	Write Slot Configuration
205	-	•	Write Slot Calibration
206	-	•	Read Firmware Version

5.3.4 OTHER OPERATING SERVICES

MODULE SERVICES	
Operating time count	
COMMON SERVICES OF THE UNITS	
Communication watchdog (comm. cycle time-out)	
RELAY UNITS' SERVICES	CURRENT GENERATORS' SERVICE
<ul style="list-style-type: none"> - Static or pulse output - Eligible pulse default state - Detection of coil splitting (error indication) - Sum of energized state times - Nr. of switching cycles - Life-time (max. numbers of switching cycles) 	<ul style="list-style-type: none"> - Monitoring correct operation of current generator (error indication)

5.3.5. RESET, TEST MODE, AND LOADING FACTORY DEFAULTS

The mentioned operations can be done, without restarting the device, with the small recessed 'RESET(TEST)' button on the front panel:

RESET	- Press
Entering TEST mode	- Press and Hold
Loading factory default settings	- Hold pressed while power on, and release when all LEDs flash red.
Attention! The current generator units should be recalibrated! The HART long addresses will change!	

TEST MODE

Once in test mode by consecutive pressing the 'RESET(TEST)' button you can cycle through the following tests. Pressing this button until all Red LEDs are flashing will exit the test mode, without pressing the button the device quits test mode after 30 seconds.

CONSECUTIVE TESTS		'COM.' LEDs (identifying tested unit)	'STATUS' LEDs correct operation:
RELAY UNIT	energized	Red	As described in 5.3.2
	de-energized		
	3.6 mA		
	4 mA		
	12 mA		
CURRENT GENERATOR UNIT	20 mA	Flashing red together	As described in 5.3.2
	22 mA		
	correct operation		
DIP SWITCH	- switching to left:	Alternate flashing red	Red flashing on 1 st unit, on 2 nd unit.
	- switching to right:		

6. MAINTENANCE, REPAIR

The device does not require regular maintenance. The warranty card contains the terms and conditions. Before returning the device for repairs, it must be cleaned thoroughly. The parts in contact with the medium may contain harmful substances; therefore, they must be decontaminated. Our official form ([Returned Equipment Handling Form](#)) must be filled and enclosed in the parcel. Download it from our website www.nivelco.com. The device must be sent back with a declaration of decontamination. A statement must be provided in the declaration that the decontamination process was successfully completed and that the device is clean from any hazardous substances.

7. STORAGE

Ambient temperature: -30...+60 °C (-22...+140°F). Relative humidity: max. 98%

pjk102en1803h
May 2018

NIVELCO reserves the right to change anything in this manual without notice!