Thank you for choosing a NIVELCO instrument!

1. APPLICATION

The level switch based on the conductive measuring principle can be applied to conductive liquids with a specific conductivity over 10^{-5} S/cm. For level detection probes are immersed into the tank. The **KKH-212** incorporates one, while the **KKH-222** incorporates two independent switching units which realize the level detection or automatic level control (filling-emptying). The transparent plastic cover allows reading the state of the switching unit without disassembling the device.

2. TECHNICAL DATA

ТҮРЕ	KKH–212–5	KKH–222–5	
No. of probes	3	5	
Material of wetted parts			
Process connection	PP		
Probe	1.4571		
Separator	PP		
Probe voltage	max. 3,5 V AC		
Probe current	< 0,1 mA AC		
Sensitivity	Adjustable: 5 kΩ…100 kΩ		
Response	max. 400 ms		
Setting accuracy	±5%		
Delay	Adjustable: 0,510 s		
t1 (not adjustable) delay	1.5 s		
Relay output	1 x SPDT	2 x SPDT	
Switching voltage	250 V AC1, 24 V DC		
Switching current	8 A AC1, 8 A DC		
Switching power	2000 VA AC1, 240 W DC		
Mechanical life-span	1 x 10 ⁷ switches		
Electrical life-span	1 x 10 ⁵ switches		
Power supply Un	24240 V AC/I	24240 V AC/DC (AC 5060 Hz)	
Voltage range allowed	Nominal volta	Nominal voltage: -15+10 %	
Power consumption	max.2 VA	max. 4 VA	
Ambient temperature	-20+50 °C	–20+50 °C (–4+122 °F)	
Medium temperature	–20+80 °C (–4+176 °F)		
Medium pressure	1 bar (*	1 bar (14.5 to psi)	
Electrical connection		Cable gland: 2× M20x1.5 Ø612 mm (Ø0.2360.47") cable;	
	terminal: max. 2.5 mm ² (AWG14)		
Electrical protection	Class II.		
Overvoltage category *	<u>I.</u>		
Pollution degree	2		
Mechanical connection		11/2" BSP	
Ingress protection			
Mass	660 g (1.45 lbs) (without probes)	800 g (1.76 lbs) (without probes)	

* EN 61010 - 1 tested with 3KV

2.3 ORDER CODE NIVOCONT 2 – NIVOCONT KLN -KKH – 2 2 CODE CODE LENGTH CODE FUNCTION CODE POWER SUPPLY 1 csatornás 24...240 V AC/DC 5 0 0 m 0 m 0 1 0,5 m 2 csatornás 2 5 1 1 m 2 2 m Szeparátor: NIVOCONT KLP-201 3 3 m

2.4 DIMENSIONS







2.2 ACCESSORIES

- User's Manual
- EU declaration of conformity
- Certificate of Warranty
- 1× O ring (EPDM)
- − 1× 1½" nut
- KKH-212
 - 3× of threaded elongation piece (joined) 6× of M6 special nut (3× joined) KKH-222
- 5× of threaded elongation piece (joined) 10× of M6 special nut (5× joined)



M6



KKH – 2 COMPACT CONDUCTIVE LEVEL SWITCH

3. INSTALLATION

The 11/2" BSP process connection on the polypropylene probe head serves for mounting the device in a tank.

ATTENTION!

Don't attempt to tighten the device holding by the plastic housing!

Before mounting the KLN-2 Each probe should be assembled using 1 elongation piece and 2 special M6 nuts for screw fastening. It is suggested that KLP-201 type PP separators be used at every 0.5 m (1.64 ft) to keep the probes apart.

ATTENTION!

Do not slew the insulated probe parts in the probe head!

The device must be protected against direct sunlight.

When placing the device take into consideration that in case of agitated liquid medium the bending or twisting forces that affects the probes may damage the unit. In this case the use of a stilling well is recommended.





Wiring can be done after removing the wiring pane. Only Un (power supply) and relay output 1 & 2 terminals should be used for wiring. In case of KKH-212 the power supply must be connected directly to the A1-A2 terminals. The figure below shows the connection terminals of the device.



The 'C' reference probe must be the longest!

5. SET UP, ADJUSTMENT

Operating mode and delay time can be set with the rotary selector switch and potentiometer on the front panel.

To set sensitivity using SENS potenciometer do the following: submerge all probes into the liquid. Set a minimal delay time (t). Adjust the sensitivity from min. to max. value until the relay becomes energised. Now set the sensitivity a little higher.



LED INDICATION

Green LED is on Red LED is on Red LED blinking Red LED is off

- power supply is on - relay is switched on (15 and 18 are closed) delay indication
- relay is disconnected (15 and 16 are closed)

SINGLE LEVEL MONITORING. In this case the probe pairs (1-2 and 3-4) should be cut to the same length. For High Fail-safe alarm indication, the 'PUMP' switch should be in UP position and for Low level alarm indication in DOWN position. Level alarm conditions are indicated in the same way (by de-energized relay state) as when a power cut-off occurs.

LEVEL CONTROL. During filling control, the 'PUMP' switch of the used relay unit should be in UP position and during emptying control in DOWN position. That way in case a power supply outage occurs (de-energized relay) overfilling or unwanted emptying is prevented.



6. MAINTENANCE. REPAIR

The device does not require regular maintenance. The warranty card contains the terms and conditions. Before returning the device for repairs, it must be cleaned thoroughly. The parts in contact with the medium may contain harmful substances; therefore, they must be decontaminated. Our official form (Returned Equipment Handling Form) must be filled and enclosed in the parcel. Download it from our website www.nivelco.com. The device must be sent back with a declaration of decontamination. A statement must be provided in the declaration that the decontamination process was successfully completed and that the device is clean from any hazardous substances.

7. STORAGE CONDITIONS

Ambient temperature: -30...70 °C (-22...158 °C) Relative humidity: max. 85%

8. WARRANTY

All NIVELCO products are warranted free of defects in material or workmanship for a period of two years from the date of purchase, as indicated in the Certificate of Warranty.

> kkh2211a0600h 03 August 2019. NIVELCO reserves the right to change anything in this manual without notice!